

Attach two Plates 3.0 to each Side Rail with one Bolt Carriage 3/8 x 1.0 and one Nut 3/8 Nyloc at each place - as shown.

Note: The attachment slots on the floats are 17.5" on-center. Be sure the Plates 3.0 are the same distance in from the end of the dock frame on each Side Rail and that they are spaced 17.5" on-center.

Attach the Float to each of the four Plates 3.0 with one Bolt 3/8 x 2.5, one Fender Washer and one Nut 3/8 Nyloc - as shown.